


# **Technical Information**

DV365

### 1 Outline

Title	Change of Flat washer 7, Compression spring 3 and H.S.H.bolt M5x20 with WR					
	DBN900, DBN901, XNB03					
	Note: These models are subject to Export Trade Control Order of Japan.					
Model	Provision of the items or technical information is strictly prohibited without specific approval of					
	Japanese government. Do not provide this information to anyone who is not permitted to handle					
	the technical information.					
Country	All countries					
Description	To improve quality.					

### 2 Detailed information



## 3 Parts information

	Item No.	Current part	Q'ty	I/C	H/S	S/P	New part	Q'ty	Note
[1]	099	FLAT WASHER 7 267426-1	1	<b></b>	NOK	L	FLAT WASHER 6 267214-6	1	DBN900 only
[2]	094	COMPRESSION SPRING 3 232354-9	1	$\downarrow$	NOK	L	COMPRESSION SPRING 3 233339-8	1	
[3]	067	H.S.H.BOLT M5X20 WITH WR 922233-6	2	<b>←</b>	NOK	L	H.S.H.BOLT M5X20 WITH WG 265D66-3	2	



# 3-1 Marks of Interchangeability (I/C), Handling (H/S), Supplying (S/P)

	Yes	The new part can be substituted for the current and the current part can be substituted for the new.					
1/0	No	The new part cannot be substituted for the current and the current part cannot be substituted for the new.					
I/C (Interchangeability)	←	The new part can be substituted for the current.					
(interchangeability)	$\rightarrow$	The current part can be substituted for the new.					
	S	Interchangeable as a set.					
H/S	OK	The current parts can be used for the subject item No(s). of the subject model(s).					
(Handling for plants, agents, and distributors stock of the	NOK	The current parts cannot be used for the subject item No(s). of the subject model(s), but can be used for the other item No(s) or the other models.					
current parts)	T	The current parts in stock must be thrown away due to the technical reason.					
	L	The plants stop supplying the current parts under the above conditions [Model(s), Countries, Item No(s).]. However, they can supply the current parts under other conditions.					
S/P	D	The plants stop supplying the current parts.					
(Supplying the current parts for repair from plants)	С	The plants continue to supply the current parts.					
repair from piants)	Z	The plants continue supplying only for a certain period or amount.					
	A	After the current parts in plant stock are cleared, they will be discontinued.					

# 4 Implementation

From the initial production